
KT Series Full Range

Product Wiring Diagram


KT48

AC Contactor Wiring Diagram



KT48

Solid State Relay (SSR) Wiring Diagram




Heater SSR Positive (+) to Terminal 5

SSR Negative (−) to Terminal 6


KT48

Alarm Light Wiring Diagram




KT48

Electrician Wiring Diagrams




KT49, KT96

AC Contactor Wiring Diagram



KT49, KT96


Solid State Relay (SSR) Wiring Diagram



KT49, KT96

Alarm Light Wiring Diagram


AC 220V Power Supply




KT49, KT96

Electrician Wiring Diagrams

Relay Output Schematic




SSR Output Schematic



KT72


AC Contactor Wiring Diagram

AC 220V Power Supply



KT72

Solid State Relay (SSR) Wiring Diagram




SSR Positive (+) to Terminal 5
SSR Negative (−) to Terminal 6

KT72

Alarm Light Wiring Diagram






KT72

Electrician Wiring Diagrams

Relay Output Schematic



SSR Output Schematic

