
TCN4 Series Full Range

Product Wiring Diagram


TCN4S

AC Contactor Wiring Diagram




TCN4S

Solid State Relay (SSR) Wiring Diagram




SSR Negative (−) to Terminal 5


TCN4S
Alarm Light Wiring Diagram




TCN4S Electrician Wiring Diagram




TCN4H, TCN4M, TCN4L
AC Contactor Wiring Diagram





TCN4H, TCN4M, TCN4L

Solid State Relay (SSR) Wiring Diagram




SSR Positive (+) to Terminal 13

SSR Negative (−) to Terminal 14

TCN4H, TCN4M, TCN4L


Alarm Light Wiring Diagram





TCN4H, TCN4M, TCN4L
Electrician Wiring Diagram

Relay Output Schematic



SSR Output Schematic

