
XMT-6000 Series Full Range

Product Wiring Diagram


XMTG-6311

AC Contactor Wiring Diagram




XMTG-6511

Solid State Relay (SSR) Wiring Diagram




SSR Positive (+) to Terminal 5
SSR Negative (−) to Terminal 6


XMTG-6311
Alarm Light Wiring Diagram



XMTG-6311, XMTG-6511
Electrician Wiring Diagram




XMTE-6311, XMTA-6311
AC Contactor Wiring Diagram



XMTE-6511, XMTA-6511


Solid State Relay (SSR) Wiring Diagram



XMTE-6311, XMTA-6311


Alarm Light Wiring Diagram






XMTE-6311, XMTE-6511
XMTA-6311, XMTA-6511
Electrician Wiring Diagram

Relay Output Schematic




SSR Output Schematic




XMTD-6311
AC Contactor Wiring Diagram

AC 220V Power Supply



XMTD-6511

Solid State Relay (SSR) Wiring Diagram




SSR Positive (+) to Terminal 5

SSR Negative (−) to Terminal 6

XMTD-6311

Alarm Light Wiring Diagram





XMTD-6311, XMTD-6511

Electrician Wiring Diagram

