
XMT-8000 Series Full Range

Product Wiring Diagram


XMTG-8411

AC Contactor Wiring Diagram




XMTG-8511

Solid State Relay (SSR) Wiring Diagram



XMTG-8411


Alarm Light Wiring Diagram




XMTG-8411 / XMTG-8511

Terminal Reference

Relay Output Terminal Reference




SSR Output Terminal Reference



XMTE-8411, XMTA-8411


AC Contactor Wiring Diagram

AC 220V Power Supply



XMTE-8411, XMTA-8411


Solid State Relay (SSR) Wiring Diagram



XMTE-8411, XMTA-8411


Alarm Light Wiring Diagram






XMTE-8411, XMTA-8411


Terminal Reference



XMTD-8411


AC Contactor Wiring Diagram





XMTD-8411

Solid State Relay (SSR) Wiring Diagram





SSR Positive (+) to Terminal 4

SSR Negative (−) to Terminal 11

XMTD-8411

Alarm Light Wiring Diagram





XMTD-8411

Terminal Reference

